

# ELNT - NOERTRANGE

Note: The following sections in this chapter are intentionally left blank: AD-2.3, AD-2.4, AD-2.5, AD-2.6, AD-2.7, AD-2.8, AD-2.9, AD-2.10, AD-2.11, AD-2.12, AD-2.13, AD-2.14, AD-2.15, AD-2.16, AD-2.17, AD-2.18, AD-2.19, AD-2.20, AD-2.21, AD-2.22, AD-2.23, AD-2.24

## ELNT AD 2.1 Aerodrome Location Indicator and Name

ELNT - NOERTRANGE

## ELNT AD 2.2 Aerodrome Data

1	<b>Coordinates</b>	495852N 0055504E
2	<b>Elevation (FT)</b>	1522
3	<b>Magnetic variation / annual change</b>	3° E (2020) / 11' E increasing
4	<b>Runway, true bearing</b>	080° / 260°
5	<b>Runway dimensions (M)</b>	657 x 30
6	<b>Slope</b>	+2.4% to W
7	<b>Surface</b>	GRASS
8	<b>Strength</b>	2250KG
9	<b>Operator</b>	Fédération Aéronautique Luxembourgeoise (FAL) 3, route d'Arlon L-8009 Strassen LUXEMBOURG
10	<b>TEL</b>	+352 95 84 30 (AD) +352 49 38 52 (OPR)
11	<b>FAX</b>	NIL
12	<b>Email</b>	<a href="mailto:fal@pt.lu">fal@pt.lu</a>
13	<b>Operational hours</b>	MON-SAT: 0830 - 1100 (0730 - 1000) and 1200 - 1900 (1100 - 1800) SUN, HOL: 0830 - 1100 (0730 - 1000) and 1300 - 1900 (1200 - 1800)
14	<b>AFIS</b>	NIL
15	<b>Procedures</b>	Circuit approach from the North. Avoid straight long final on RWY 08 due to obstacle (church tower) aligned on extended centre line.
16	<b>Remarks</b>	Aerodrome operations under VMC and day conditions only. The use of the aerodrome is subject to prior permission from the operator. Permission can only be granted when requested by phone at least 1 hour prior to the flight. The use of the aerodrome is subject to the presence of a person in charge designated by the operator. ULM and HEL: PPR from CAA (see GEN 1.1, § 1.2). Aerodrome available for single-engine aircraft only. Parachute jumping at aerodrome. "Noertrange" - A/A 126.955 (8.33 KHZ CH) - No ATS.

THIS PAGE INTENTIONALLY LEFT BLANK